BIL SOLUTIONS
bilsolutions.co.uk

CHECKLIST

Surface contamination scanning checklist

- [ ] Measure background count rate in a clean area before starting your survey
- [ ] Move the probe slowly and steadily, listening for changes in count rate
- [ ] Mark any spot where the count rises above background and return for a static measurement
- [ ] Record the highest reading and its location in your survey log
- [ ] Check the probe window for damage after each survey
- [ ] Store the instrument with the protective cap in place
- [ ] Test the detector with a check source before each use